



The exhaust duct should be aligned left to right with the left and right edges of the bottom spacer. The front edge of the exhaust duct should be recessed from the edge of the bottom spacer by 5 mm in order for the unit to be flush with the front surface of the trim kit. The exhaust duct should be secured to the bottom spacer with Screw (C).



