




Frigidaire

Factory Parts Catalog

Product No.	PLGF659ECA
	30857636F50S1
Series	36" f/s gas
Color	stainless
Market	North America
Wiring Diagram	318045813
Owner's Guide	318200760
Installation Instructions	318201760
Service Data Sheet	318127026
Timer Guide	318200176

 **Electrolux**

Electrolux Major Appliances
North & Latin America
P.O. BOX 212378
AUGUSTA, GA 30917


Publication No.
5995454252
05/11/16
(EN/SERVICE/ECL)
377

**36-INCH FREE-
STANDING GAS
RANGE**

Model No.
PLGF659E

Copyright © 2005 Electrolux Home Products, Inc.
All rights reserved.


BACKGUARD



C75403500

BACKGUARD


POS. NO	PART NO.	DESCRIPTION
1	318316310	Cover, rear, upper
9	318339100	Bracket, mounting, service cord
19	318331100	Control Panel Assembly, stainless, w/glass
20 #	316418549	Clock/Timer, electronic, ES340-350
23	318316201	Bracket, timer
99	5303304544	Spacer, end cap mtg.
*	318224714	Wiring Harness, backguard
*	318224715	Wiring Harness, backguard
*	318163602	Cleaner, stainless steel
*	5303131801	Screw, 10 x 3/8
*	5303311333	Screw, 8-32 x 3/8

BURNER

BURNER

POS. NO	PART NO.	DESCRIPTION
1 #	318315700	Manifold Pipe
2 #	318234021	Valve, top burner, 17K
2A #	318234025	Valve, top burner, 5K
2B #	318234024	Valve, top burner, 9.5K
2C #	318234022	Valve, top burner, 14K
2D #	318234023	Valve, top burner, 12K
3 #	318232613	Wiring Harness, w/igntr switch
8	318079001	Module, spark
*	318199745	Wiring Harness, spark module
10 #	316223300	Burner, sealed, 17K
10A#	316206400	Burner, sealed, 5K
10B#	316212400	Burner, sealed, 9.5K
10C#	316223400	Burner, sealed, 14K
10D#	316212300	Burner, sealed, 12K
11 #	318221357	Ignitor/orifice assy., top burner, center, 17K, w/holder, tube
11A#	318221351	Ignitor/orifice assy., top burner, right rear, 5K, w/holder, tube
11B#	318221352	Ignitor/orifice assy., top burner, left rear, 9.5K, w/holder, tube
11C#	318221354	Ignitor/orifice assy., top burner, left front, 14K, w/holder, tube
11D#	318221355	Ignitor/orifice assy., top burner, right front, 12K, w/holder, tube
13	318054511	Tube, connection, manifold
14 #	316091706	Regulator, pressure
15	318262800	Bracket, regulator
16	318054512	Tube, regulator, to safety
17 #	316031400	Valve, safety
18 #	5303311544	Burner, oven
19	318177720	Ignitor, oven burner
20	5308011508	Baffle, oven burner
21	3201885	Nut, Keps, 10-24
22	318249301	Tube
23 #	5303311548	Burner, oven broil
24 #	5303311547	Elbow, mixer
26	318177730	Ignitor, broil burner
37	316240600	Screw, assy mtg, ignitor/orifice
44	316237912	Orifice, top burner, 16K
44A	316237903	Orifice, top burner, 5K
44B	316237902	Orifice, top burner, 9.5K
44C	316237900	Orifice, top burner, 14K
44D	316237901	Orifice, top burner, 12K
57	318340500	Bracket, spark module
69	3131871	Shield, oven ignitor
72	316215600	Screw, valve mtg., 1/4 - 20
77	318192600	Bracket, burner mtg, (5)
*	318186912	LP Conversion Kit
*	5303324193	Bushing, snap, nylon
*	5303131801	Screw, 10 x 3/8
*	5303300195	Screw, 10-32 x 0.375, terminal block, (2)



BODY



BODY

POS. NO	PART NO.	DESCRIPTION
1	318076305	Back, main
3	318317903	Panel-bodyside, black
5	318175503	Screw, leveling
5*	08013303	Tee nut, snap-in, levelling screw
6	318315810	Rack, oven, (2)
7	318348800	Hinge Assy, RH
7A	318348801	Hinge Assy, LH
*	3051070	Screw, hex washer head, 10-24 x 0.438, special
8	318135500	Panel, oven bottom, insert
9	5303317977	Pan, broiler
10	5303317976	Insert, broiler pan
12 #	318089916	Switch, light
*	318231824	Harness, wiring, door switch
14	318224000	Receptacle, oven light
15	5303013071	Bulb/Lamp, light
16	3201911	Cover, oven light, glass
17	5303205904	Clip, lamp cover, retainer
36	318316100	Box, flue assy.
37 #	316217002	Probe, oven temp
39	318144008	Cord, service
40	318133300	Baffle, broil burner
42	318168700	Baffle, oven burner
54	5303271606	Housing, oven light
56	318315200	Trim, vertical, stainless, front, (2)
58A	318285080	Insulation, top & sides, oven wrapper
58B	318285081	Insulation, top & back, oven wrapper
58C	318285088	Insulation, flue, (3)
74	3051063	Grommet, bodyside
76	318320801	Frame, oven, front
77	318166702	Rail, base
83	318134400	Liner, oven, RH
83A	318134401	Liner, oven, LH
84	318134700	Frame, oven bottom
85	318088400	Spring, oven door, (2)
85*	5303207651	Spring, oven door, (1)
86	318135300	Liner, oven, back
88	318118906	Rod, latch
89	318095951	Motor, latch assy, w/brkt & switch
89*	3201861	Screw, 6 x 0.375, (4)
89*	318120711	Switch
98	318332800	Channel, latch rod
108	318073002	Blower, fan
120	3051096	Support, oven rear
128	5303311163	Bushing
*	5303311528	Screw, oval hd sq dr, 6-20AB x 0.625, black
129	5303311164	Spring
140	5304405240	Anti-tip accessories
147	318168400	Support, safety valve
147A	08068039	Support, control valve
149	3131046	Channel, wiring
154	318076600	Pan, oven burner
*	3201885	Nut, Keps, 10-24
155	318160600	Shield, door lock, btm
189	318322800	Angle, rear plenum, (2)
*	5303211311	Screw, 8 x 0.500
209	5303286692	Support, rail
219#	318003606	Thermostat, safety
230	318134511	Liner, oven
241	318121200	Retainer, btm insulation
241*	3201899	Washer, flat
*	318224706	Wiring Harness, chassis
*	5303131801	Screw, 10 x 3/8

TOP/DRAWER




TPLGF659ECA

TOP/DRAWER

POS. NO	PART NO.	DESCRIPTION
1	318157611	Drawer, storage, black
2	318336500	Panel, insulation, upper
3	318336100	Divider, vent box, side
3A	318336200	Divider, vent box, center
4	318315100	Panel, drawer, stainless, outer
7	318332200	Roller, nylon, (2)
11	318316000	Bracket, Drawer Panel, (2)
*	5303300265	Screw, 8-18 X 1/2, (2)
13	5303051055	Channel, drawer, RH
13A	5303051056	Channel, drawer, LH
16	318185211	Main Top Assy, glass, black
20	318221760	Grate, black, (2)
20A	318221759	Grate, black, center
21	316264803	Skirt, 17K burner, black
21A	316241904	Skirt, 5K burner, black
21B	316241804	Skirt, 9.5K burner, black
21C	316264903	Skirt, 14K burner, black
21D	316241704	Skirt, 12K burner, black
22	316271904	Cap, 17K burner, black
22A	316206604	Cap, 5K burner, black
22B	316213505	Cap, 9.5K burner, black
22C	316219905	Cap, 14K burner, black
22D	316213605	Cap, 12K burner, black
31	316242004	Seal, 17K burner
31A	316242003	Seal, 5K burner
31B	316242002	Seal, 9.5K burner
31C	316242000	Seal, 14K burner
31D	316242001	Seal, 12K burner
33	318341400	Knob, control, (5)
35	318341300	Skirt, (5)
39	318039801	Handle, door, stainless steel, oven
46	318336300	Deflector, ventilation
50	318315900	Deflector, flue
51	318315300	Gasket, flue deflector
52	5304442349	Pushnut, flue deflector, (2)
60	5304400794	Screw, handle mtg, 10-32 x 3/4
69	5303308450	Screw, 8 x 0.375
124	318336400	Box, vent
*	318163600	Cleaner, cooktop
*	318163602	Cleaner, stainless steel
*	5303131801	Screw, 10 x 3/8
*	5303311174	Screw, 10-24 x 3/8

OVEN DOOR



D75403500

OVEN DOOR

POS. NO	PART NO.	DESCRIPTION
6	318319600	Shield, insulation, door
*	3051050	Screw, shoulder
7	318285082	Insulation, oven door
7A	318294908	Insulation, door
8	5303271567	Glass, oven door, inner
9	318157211	Panel, door, inner
10	5304400794	Screw, handle mtg, 10-32 x 3/4
11	318065102	Latch, door
*	5304415832	Screw, 8-18 x 0.406
12	318053140	Seal, oven door
13	318344001	Door Assmebly, stainless, w/glass
15	318122100	Bracket, glass mtg
16	318041610	Glass, oven door, heat barrier
29	318147412	Bumper, base
32	318057202	Panel, heat deflector, door handle
33	318294910	Insulation, deflector, door
39	318039801	Handle, door, stainless steel, oven
57	318172902	Stiffener, glass
*	316221001	Label, anti-tip
*	318163602	Cleaner, stainless steel
*	5303131801	Screw, 10 x 3/8

WIRING DIAGRAM

