


FACTORY PARTS CATALOG

DISHWASHER

Frigidaire

 **Electrolux**



PRODUCT NO.	BASE MODEL NO.	SERIES	COLOR
FDS252RBS1	FDS252RB	18" Portable	white
MARKET			
North America			

SERVICE DATA SHEET # - 154443001
OWNER'S GUIDE # - 154418701
ENERGY GUIDE LABEL # - 154399019

 **Electrolux**

ELECTROLUX HOME PRODUCTS, INC.
P.O. Box 212378, Augusta, GA 30917

Publication No.

5995380481

021030


-EN/SERVICE /ECL
821

**18" Portable
DISHWASHER**

**Model No.
FDS252RB**

©2002 Electrolux Home Products, Inc.
All rights reserved


CONTROL PANEL



CONTROL PANEL

POS. NO	PART NO	DESCRIPTION
1	154357602	Panel,control ,white
2	154418601	Insert,control panel ,white
3 #	154437301	Timer
3*	154131203	Shield,timer
3*	154095701	Screw,thread rolling ,(2) ,timer
8 #	154220401	Switch,selector ,5 button
8*	154242201	Shield,switch
8*	5303318719	Screw,mtg.
11	5304428149	Lens,light
12	154236502	Pushbutton,white
13	154239504	Knob,timer ,white
* #	154438001	Wiring Harness
*	154416601	Shield,wire ,white
*	154399019	Label,energy guide



DOOR



P30B0031

DOOR

POS. NO	PART NO	DESCRIPTION
1	154237401	Spring,door ,(2)
2	154093301	Screw,arm assy ,(4)
3	5303270031	Arm Assy,RH & LH
3*	154221401	Cover,arm assy
3*	5303298513	Pin,arm assy
4	5300805884	Pad,door spring
5	154079601	Nut,arm assy ,and handle mtg.
7	154352201	Door,inner assy
9	154230103	Dispenser,det/rinse aid ,includes #22
9*	154294701	Screw,#7 plas .375 ,(6) ,disp. assy.
10	154419401	Screw,access panel ,white
11 #	154221101	Baffle,door ,white
12 #	154361201	Latch assy,white
15	154103702	Screw,latch mtg ,(2)
20	154416101	Panel,outer door assy ,white
21	154411301	Panel,access ,white
22	154388801	Cap,Rinse aid
28	154400301	Trim,access panel ,white
30	154026601	Speednut,door baffle
43	154229301	Cover,vent
43*	154229401	Screw,vent cover ,(2)
44	154221001	Gasket,vent cover
51	154320301	Clamp,drip loop ,wire
* #	154227808	Thermostat,temp boost
*	154395501	Retainer,thermostat




P30U0019

TUB

POS. NO	PART NO	DESCRIPTION
1 #	154218701	Tub assy,w/gasket
2	154429101	Strike,door
3 #	154219501	Gasket,tub
4	154200601	Screw,#10-16 x 3/8
5	154333902	Roller,tub
6	5303943103	Screw,w/washer ,(8)
22	154239801	Tubing,water inlet
23	5303318539	Clamp,tubing ,(2)
25 #	154209701	Float
26	154242302	Trim,tub flange ,RH
26	154242303	Trim,tub flange ,LH
*	154238301	Insulation,tub


MOTOR & PUMP



MOTOR & PUMP

POS. NO	PART NO	DESCRIPTION
1 #	154220901	Heater
1*	154289801	Shield,heater terminal
2	154359701	Bracket,heater ,(2)
3	154106201	Nut,heater ,(2)
7	154365101	Macerator
10	154365302	Cover,volute
12	154365401	Impeller,lower drain
12A	154365501	Slinger,pump
14	154364802	Housing,pump
15 #	154367701	Check valve
16	154246502	Retainer,sump
18 #	154384301	Motor
22	154200201	Screw,pump housing
23	154234301	Nut,spray arm
24	154219201	Spray arm,lower
24*	154232601	Shield,heat ,spray arm
27	154377501	Screw,upper impeller
28	154370601	Impeller,upper
34	154064901	Washer,insulating
35	154200901	Screw,motor mtg
36	154387601	Sleeve & seal assy.
38	154367402	Diffuser
42	154365601	Gasket,pump
44	154122502	Base,tower
45	154122601	Middle,tower
46	154122701	Tip,tower
52	154365201	Cover,pump housing
*	154106801	Clamp,hose ,(2)
*	154200601	Screw,#10-16 x 3/8

FRAME





P30F0025

FRAME

POS. NO	PART NO	DESCRIPTION
1	154218801	Front frame assy
1A	154236102	Bracket,front frame
2	154200601	Screw,#10-16 x 3/8
3 #	154373303	Valve,water
4	154219101	Brace,front frame
5	154408701	Switch assy,float
7	5300804672	Screw,start relay
10	154200602	Screw,10-16 x 3/8 ,hex
12 #	154380001	Relay,motor start
15	154419301	Screw,leveling
16	154292701	Frame,assy ,rear
19	154280201	Caster,30
26 #	154187106	Hose & Coupler Assy
27	154229602	Wrapper,white ,back
27A	154229702	Panel,side,RH
27B	154229701	Panel,left side
28	154242402	Base and Weight Assy
28*	154243201	Clip,(2)
29	154242501	Adapter,water valve
31	5303304813	Faucet Adapter Assy
32	154405802	Top
33	154241701	Screw,top
34	154249701	Pocket,lower
34A	154249801	Pocket,upper
34A*	154025901	Screw,truss head ,10 x 0.625
35 #	154253001	Cord,electric
*	154257901	Clip,cable
*	154041001	Screw,plask #1 ,10-10 x 9/16

RACKS



P30R0021

RACKS

POS. NO	PART NO	DESCRIPTION
1	154239101	Rack assy,lower
2	5300808994	Basket,silverware
3	154237502	Rack assy,upper
4	5304407064	Wheel & bushing assy,upper rack
5	5300809927	Cap,slide ,(4)
6	154232701	Slide,rack ,(2)
7	154174501	Wheel & bracket assy,lower rack
11	154225203	Shelf,cup
12	154352401	Bracket,cup shelf ,(4)