




Frigidaire

Factory Parts Catalog

Product No.	PLEF489CCF
	38157596G30S6
Series	40" f/s elec
Color	stainless
Market	North America
Wiring Diagram	318045328
Owner's Guide	318200706
Installation Instructions	318201701
Service Data Sheet	318047204
Timer Guide	318200181

 **Electrolux**

Electrolux Major Appliances
North & Latin America
P.O. BOX 212378
AUGUSTA, GA 30917


Publication No.
5995458816
06/01/17
(EN/SERVICE/ECL)
377

40-INCH FREE- STANDING ELECTRIC RANGE

Model No.
PLEF489C

Copyright © 2005 Electrolux Home Products, Inc.
All rights reserved.

BACKGUARD




LA00BG81596-2B

BACKGUARD

POS. NO	PART NO.	DESCRIPTION
1	318086900	Shield, backguard
12A#	318183000	Thermostat, oven
14 #	318044824	Light, indicator, 250v, (2)
14A#	318044823	Light, indicator, 125v, (1)
15	318161902	Bracket, end cap, RH
15A	318161903	Bracket, end cap, LH
16	318193110	Panel, switch mtg
16A	318182410	Panel, switch mtg
18	318190604	End Cap, RH
18A	318190605	End Cap, LH
19	318192922	Panel, control
19A	318181820	Glass, control panel
20 #	318010102	Clock/Timer, EOC, ERC3
24 #	316005602	Switch, rocker, black
28A	316080600	Shaft, push button, black, (11), clock/timer/EOC
29	318017800	Knob, clock, black, (11)
32A	318099205	Knob, thermostat
36	318099202	Knob, control
36A	318099207	Knob, dual control
36B	318099206	Knob, warm zone
54 #	318220071	Switch, surface unit, small
54A#	318220073	Switch, surface unit, large
54B#	318191000	Switch, infinite, dual
54C#	318078801	Switch, element, 6", warmer
69	5303323134	Screw, 8-32 x 0.188
69A	5304401837	Screw, 8-32 x 5/16
80 #	318111501	Relay, convection, oven light, (1)
99	5303304544	Spacer, end cap mtg.
*	08016432	Screw, truss head, 8-18 x 0.375
*	5303211311	Screw, 8 x 0.500

BODY




LA00B81596-1H

BODY

POS. NO	PART NO.	DESCRIPTION
1	318066415	Panel, main back
3	318066134	Panel, bodyside, black, RH
3A	318066135	Panel, bodyside, black, LH
4	318073714	Panel, subtop
5	318175503	Screw, leveling
6	318025304	Rack, oven
6A	318219500	Rack, broiler pan
6B	318119700	Rack, shelf, small oven
8	318133000	Panel, heat shield, small oven
8A	318071900	Panel, small oven, bottom
9	5303317977	Pan, broiler
10	5303317976	Insert, broiler pan
12 #	318089913	Switch, light
12A#	5301314211	Switch, oven light, sm door frame
14	318224000	Receptacle, oven light
15	5303013071	Bulb/Lamp, light
16	3201911	Cover, oven light, glass
17	5304400195	Retainer, light cover
17A	5303205904	Clip, lamp cover, retainer
25	318179113	Shield, bottom
27	5303284616	Clip, thermo bulb mtg
30	318023921	Bracket, main top
36	318182111	Support, flue conduit
37 #	316217002	Probe, oven temp
41	5303310526	Cover, hinge cutout
54	318222400	Housing, oven light
54A	5303271606	Housing, oven light
57	318055701	Panel, small oven back
58A	318285017	Insulation, oven wrapper
58B	318285018	Insulation, oven back
58E	318285005	Insulation, wrapper, small oven
58F	318285006	Insulation, back, small oven
59	318072544	Tube, oven vent
59A	318072550	Tube, oven vent, LH
62	5303935061	Terminal Block Kit
62*	5303323139	Screw, 10-24 x 0.906
62*	5303323144	Nut, 10-32
63	318264200	Plate, grounding strap
66 #	318255600	Element, broil, 2750W
66A#	318255700	Element, broil, small oven
67 #	318255000	Element, bake, 3000W
67A	318255200	Element, bake, small oven
68	5304403015	Support, hanger, (2), broil element
71	5303310515	Panel, wiring cover, rear
74	318147420	Bumper, base
76	318056006	Frame, oven, front
77	318144211	Bracket, slide
80	5303320846	Plate, oven mtg
81	318192400	Spring, oven
83	318089617	Liner, oven assy
83A	318089200	Liner, small oven


BODY



BODY

POS. NO	PART NO.	DESCRIPTION
84	5303326184	Gusset, RH rear
84A	5303326185	Gusset, LH rear
84B	318055902	Gusset, rear
86	5303310524	Receptacle, hinge
87	318111800	Plate, cord set mtg
88	5303311160	Rod, latch
89 #	318095940	Motor, latch assy, w/brkt & switch
89*	318120711	Switch
100	318182011	flue conduit inf.
102	318111901	Channel, oven support, black
104	318182212	Adapter, flue
107	318219401	Cover, fan
109	5303311203	Blade, fan
111	316136600	Nut, fan retainer
112#	318112701	Relay
125#	5303311202	Motor, convection
127	318317100	Adapter Assembly, vent tube, w/converter
128	5303311163	Bushing
129	5303311164	Spring
137	318090300	Latch, door
139	318042900	Bracket, filler
140	318071300	Plate, insul retainer
142	318123901	Deflector
161#	318255500	Element, convection, 2500 W
170	5304405241	Anti-tip bracket
177	318053810	Gasket, vent
191	318322800	Angle, rear plenum, (2)
219#	318003600	Thermostat, safety
260	318055500	Bracket, gusset support
261	08014183	Pan, broiler, small oven
262	08011954	Channel, oven support, front
263	316136500	Washer, flat
*	318235300	Connector assy., w/3 lugs, & instructions
*	318249400	Tube, protector
*	08016432	Screw, truss head, 8-18 x 0.375
*	5303211311	Screw, 8 x 0.500
*	5303307980	Screw, 8-32 x 0.437, (4)


MAIN TOP



LA00CT81596-2A

MAIN TOP

POS. NO	PART NO.	DESCRIPTION
15 #	318198817	Element, surface, 6", 1200 W, (2)
15A#	318198923	Element, surface, 6/9, 1000/2000w, dual radiant
15B#	318198825	Element, surface, warmer, 100 W
15C#	318258201	Element, bridge, 1800/2600
16	318159632	Maintop, glass, stainless/blk
51 #	318044822	Light, indicator, clear
52	318122006	Spring, element mtg, small
52A	318122007	Spring, element mtg, large
52B	318122004	Spring, element mtg, 700W & 2100W
52C	318122008	Spring, element mtg
53	318125906	Bracket, indicator light, hot surface
*	08016432	Screw, truss head, 8-18 x 0.375
*	5303211311	Screw, 8 x 0.500
*	5303300265	Screw, 8-18 X 1/2, (2)


SMALL DOOR/DRAWER

LA00D81593-1A

SMALL DOOR/DRAWER

POS. NO	PART NO.	DESCRIPTION
1	3202108	Drawer, utility
2A	318048221	Liner, inner door, small oven
2A*	318229000	Baffle, small door
4	318158221	Panel, drawer
4A	318009321	Panel, oven door, stainless, small
5	318014511	Spacer, door handle
13	318259503	Glide, warmer, inner RH
13A	318259502	Glide, warmer, inner LH
29	318141800	Spacer, hinge pin, upper/lower
30	318285016	Insulation, oven door
39	318039803	Handle, door
39A	318039802	Handle, door, small oven
60	5303323139	Screw, 10-24 x 0.906
61	318107700	Toeplate
63	318024508	Hinge, door, lwr small oven, lower
63A	318024509	Hinge, door, upr small oven
65	318090220	Strike, door
69	318053110	Seal, small oven door
96	3201899	Washer, flat
124	316105501	Glide, warmer drawer, outer/RH & LH, (2)
139	5304400794	Screw, handle mtg, 10-32 x 3/4
193A	5303321106	Plug, button
*	318163602	Cleaner, stainless steel
*	08016432	Screw, truss head, 8-18 x 0.375
*	5303211311	Screw, 8 x 0.500

OVEN DOOR



OVEN DOOR

POS. NO	PART NO.	DESCRIPTION
6	318057020	Shield, insulation, door
7	318285050	Insulation, oven door
7A	318285096	Insulation, oven door
9	318156911	Door, inner
12	318253002	Gasket, oven door seal
13	318187927	Stainless Panel, oven door, w/glass & nmplt
15	318172904	Support, wire
16	318041603	Panel, glass, inner oven door
17	318042102	Spacer, glass
18	318293501	Gasket, door glass seal
22	5303310511	Bar, glass retainer
23	318024721	Hinge, lower door, (2)
23*	3201899	Washer, flat
29	318147412	Bumper, base
31	5303310536	Latch, oven door
39	318039801	Handle, door, stainless steel, oven
54	5303300265	Screw, 8-18 X 1/2, (2)
60	5304400794	Screw, handle mtg, 10-32 x 3/4
*	316221001	Label, anti-tip
*	318163602	Cleaner, stainless steel
*	08016432	Screw, truss head, 8-18 x 0.375
*	5303211311	Screw, 8 x 0.500
*	5303307980	Screw, 8-32 x 0.437, (4)

WIRING DIAGRAM

