


Quick reference guide



Upright Vacuum Cleaner S 7000


To prevent accidents and machine damage, read the attached operating instructions before installation and use.

en - US, CA


M.-Nr. 07 450 370

Using the vacuum cleaner


Assembling the vacuum cleaner




Releasing the body of the vacuum cleaner




Releasing / Rewinding the power cord



Align cord with notch





Turning the vacuum cleaner On/Off



Using the vacuum cleaner


Selecting the flooring type





Turning the Powerbrush On/Off



Fitting the vacuum Hose and Wand



Telescopic wand




Using the vacuum cleaner / Maintenance


Included accessories




Lifting the head of the vacuum




Airflow indicator




Opening the dust compartment



Releasing the dustbag



Inserting the dustbag



Please read the operating instructions to see how to change the exhaust filters.