




## **24" ELECTRIC WALL OVEN**

### **MODELS:**

WOS11EM4EB01 (Black)

WOS11EM4EW01 (White)


# CONTROL PANEL PARTS



# CONTROL PANEL PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	2		Assembly, Control Panel Skin	7	W10794084	Fuse, Thermal
	W10758337	Guide, Use & Care		W10702189	Black			FOLLOWING PARTS NOT ILLUSTRATED
	W10758285	Instructions, Installation		W10704698	White		W11157780	Harness, Main
	9762761	Tips, Safe Cooking (English)	3	W10752315	Interface (Maxwell), User Board		W11157913	Harness, Door Latch
	W10776932	Sheet, Tech	4	W10721212	Control		W11157775	Harness, EOL (MRC)
	W10767149	Diagram, Wiring	5		Assembly, Membrane		4450800	Screw, Grounding
				W10694998	Black		4448664	Clamp, Conduit
				W10694999	White		4451761	Support, Wiring
			6	7101P427-60	Screw		4454842	Tie, Cable


# OVEN PARTS



# OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8285593	Cover, Connector	15	4455380	Gasket, Door	30	4449154	Screw
2		Trim, Side	16	7101P426-60	Screw	31	4450118	Nut
	W10756499	Black (Left)	17	4449743	Screw	32	4450038	Screw
	W10756500	Black (Right)	18		Assembly, Bottom Vent Trim	33	4451747	Cover, Back
	W10756495	White (Left)		W10339572	Black	34	W10804302	Bracket, PCB Support
	W10756496	White (Right)		W10339573	White	35	W10720084	Screw
3	4455605	Receiver, Hinge (Left)	19	4451476	Support, Insulation	36	7101P434-60	Screw
	4455606	Receiver, Hinge (Right)	20	4451605	Cap, Spacer	37	694091	Screw
4	W10105790	Bumper & Screw	21	4450580	Rail, Side (Left)			FOLLOWING PARTS NOT ILLUSTRATED
5	W10784805	Switch, Door Light		4450579	Rail, Side (Right)		4449314	Insulation, Wrap
6	4448933	Retainer, Gasket	22	W10777627	Thermostat		4450363	Insulation, Back
7	W10784377	Chassis, Top	23	4449040	Screw		W10772942	Insulation, Side Rail
8		Deflector, Vent Box	24	4448444	Grommet, Mounting Rail		W10772943	Retainer, Side Rail Insulation
	4455807	Black	25	W10782197	Side, Chassis			
9	W11085338	Tube, Vent	26	W10784207	Back, Chassis			
10	W10734063	Assembly, Light	27		Liner, Oven (Not Serviceable)			
11	W10412722	Lens, Light	28	4452152	Bracket, Bottom Vent			
12	W10412711	Bulb, Light	29	W10622170	Probe, Sensor			
13	4450525	Base, Chassis						
14	9760754	Frame, Front						


# TOP VENTING PARTS



# TOP VENTING PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	4451758	Block, Foam	7	4448664	Clamp, Conduit	12	W10790240	Side, Control Top (Left)
2	4451759	Vent, Exhaust	8	4455178	Elbow, Top Vent			
3	W10176670	Blower (65MM)	9	4455177	Elbow, Bottom Vent		W10755214	Side, Control Top (Right)
4	4452365	Cover, Top Front	10	4450549	Cover, Top Rear			
5	7101P426-60	Screw	11	8303100	Back, Control			
6	4448547	Vent, Control Panel						

# OVEN DOOR PARTS








# OVEN DOOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	8303698	Liner, Door	6	W10292297	Screw	10	488130	Nut
2	9760564	Hinge, Door (Left)	7		Assembly, Door Handle	11	W10708952	Bracket, Handle
	9760563	Hinge, Door (Right)		W10684319	Black	12		Assembly, Door
3	4449247	Glass, Inner		W10684321	White		W10692585	Black
4		Clip, Retainer	8	4448520	Bumper, Door		W10692586	White
	W10789031	Black	9		Badge	13	3400832	Screw (Black)
	W10789030	White		W10481433	Grey	14	8300853	Seal, Door Top
5	4457130	Retainer, Glass		W10481434	White			

# INTERNAL OVEN PARTS



# INTERNAL OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10685631	Element, Broil
2	4449154	Screw
3	7101P426-60	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	4448716	Rack, Oven
5	W10745723	Element, Bake

# OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		PAINT, SPRAY
	350930	White
	261900	Citrine White
	830864	Black
		ADHESIVE
	591014	Adhesive, Loctite
	482338	Sealer, Silastic
		ACCESSORIES
	W10355049	Wipes, Stainless Steel Cleaning
	W10355016	Cleaner, Stainless Steel
	W10275756	Cleaner, Granite
	4396923	Grid, Broiler Pan and