

#### CLASSIC REFRIGERATION AND WINE STORAGE

- 1 Touch POWER to turn off the unit.
- 2 Touch and hold POWER for 10 seconds.
- 3 SAb appears on the display.

#### DESIGNER REFRIGERATION AND WINE STORAGE

- 1 With the unit on, touch ►.
- 2 Touch ⚙️.
- 3 Touch and hold ☆ for three seconds.

#### PRO REFRIGERATION

- 1 If the automatic display lock is turned on, touch and hold ⏸ for three seconds.
- 2 Tap ⚙️.
- 3 Tap ► twice.
- 4 Touch and hold ☆ for three seconds.

#### 648PRO REFRIGERATION

- 1 Touch POWER to turn off the unit.
- 2 Touch and hold POWER for 10 seconds.
- 3 The unit chimes four times to indicate Sabbath mode is on.

#### UNDERCOUNTER REFRIGERATION

**Note:** Sabbath mode is not available on ice machines.

- 1 Touch POWER to turn off the unit.
- 2 Touch and hold POWER for 10 seconds.
- 3 SAb appears on the display.

