




36" GAS COOKTOP

MODELS:

WCG97US6HS00 (Stainless)


COOKTOP, BURNER AND GRATE PARTS



COOKTOP, BURNER AND GRATE PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8	8286814	Head, Burner (Left Front & Left Rear)	15	W10758282	Screw
	W11116971	Instructions, Installation		8286813	Head, Burner (Right Rear)	16	W10685483	Griddle
	W10672375	Instructions, Undercounter Install		8286815	Head, Burner (Right Front)			FOLLOWING PARTS NOT ILLUSTRATED
	W11120470	Guide, Use & Care	9		Grommet	W10868533		Harness, Main
	W11168236	Instructions, LP Conversion	10	W10625915	Black	W10392003		Cord, Power
2		Cooktop	10	W10826075	Rear, Hinge-Grate (Stainless Model Only)	W10132200		Relief, Strain
	W11131862	Stainless	11	W10652710	Orifice (Left Front & Left Rear)	313438		Clip, Harness
3		Kit, Burner Cap		W10409144	Orifice (Right Front)	W11173306		Kit, LP Conversion
	W10597132	Black		W10652711	Orifice (Right Rear)	3801F935-51		Bracket, Tie Down
4		Kit, Grate		W10597160	Orifice (Center, Main)	7101P062-60		Screw (Used for Tie Down Bracket)
	W11047088	Black		W10151362	Orifice (Center, Simmer)	9760045		Seal, Foam
5	8286863	Spring, Electrode	12	W10541842	Wiring, Electrode (Left Front & Right Front)	8270P188-60		Tape, Foam
6		Knobs, Cooktop		W10541843	Wiring, Electrode (Left Rear & Right Rear)			
	W11084624	Stainless	13	W10611434	Head, Burner			
7	W10597166	Holder, Orifice (9.1K) (Left Front & Left Rear)	14	W10763330	Electrode, Stack (Center)			
	W10594405	Holder, Orifice (12K) (Right Front)						
	W10594399	Holder, Orifice (5K) (Right Rear)						
	W11168368	Holder, Orifice (18K) (Center)						

BURNER BOX, GAS VALVES AND SWITCH PARTS



BURNER BOX, GAS VALVES AND SWITCH PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	8287057	Screw, Valve Bracket	5	8287056	Bracket, Dual Valve	14	W10566308	Tubing, Gas Burner (Right Front)
2	W10594397	Assembly, Pipe Manifold	6	W10614951	Panel, Front	15	W10566307	Tubing, Gas Burner (Right Rear)
3	W10594392	Valve, Single (Left Front)	7	W10449143	Regulator, Pressure	16	W10566296	Tubing, Gas Burner (Center, Main)
	W10594391	Valve, Single (Left Rear)	8	W10594429	Bracket, Orifice Holder	17	W10566297	Tubing, Gas Burner (Center, Simmer)
	W10594393	Valve, Single (Right Front)	9	W10475149	Module, Spark (5+0)	18	W10594430	Bracket, Orifice Holder
	W10597156	Valve, Single (Right Rear)	10		Box, Burner (Not Serviced)	19	W10443110	Screw
	W10594389	Valve, Dual (Center)	11	W10140571	Seal, Switch Shaft	20	7101P426-60	Screw
4	8287055	Bracket, Single Valve	12	W10566305	Tubing, Gas Burner (Left Front)			
			13	W10566306	Tubing, Gas Burner (Left Rear)			