




**30" ELECTRIC FREESTANDING STANDARD CLEAN RANGE
Finger Print Resistant**

MODELS:

WFE975H0HZ1 (Stainless)

WFE975H0HV1 (Black Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	4		Cooktop	7	W10691223	Pan, Radiant Element
	W11085337	Instructions, Installation		W10865061	Black	8	W10306542	Bracket, Anti-Tip
	W11085358	Use and Care Guide	5	W10342780	Element (1300W) (Left Rear)	9	7101P485-60	Screw, Anti-Tip Kit
	W11096112	Tech Sheet (English)		8273994	Element (1200W) (Right Rear)			FOLLOWING PARTS NOT ILLUSTRATED
	W11096060	Guide, Quick Start (English/French)		W10275048	Element (3000/1400W) (Right Front)	W11176673		Harness, Main
	W11097305	Guide, Internet Connectivity		W10799048	Element, Warm Zone (Center Rear)	W11134592		Harness, Warm Zone
2	W10225448	Spring, Element		W10187839	Element (3000W) (Left Front)	W11025427		Harness, WiFi Module
3	W10607641	Bracket, Cooktop (Left)				W11134550		Harness, Cooktop (Right)
	W10607642	Bracket, Cooktop (Right)	6	3196169	Screw	W11190446		Harness, Cooktop (Left)
						3196520		Clip, Wire


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	6		Bracket, Eye Brow
	W11213290	Black (Left)		W11051312	Black
	W11213292	Black (Right)	7		Knob
2	W10888670	Assembly, WiFi		W10917219	Stainless
3		Console		W10917220	Black Stainless
	W10869991	Stainless	8	W10134247	Shield, Heat
	W10881625	Black Stainless	9	3400882	Screw
4	W10437097	Switch, Infinite (Left Front)	10	8272473	Cover, Upper Rear
	W10437092	Switch, Infinite (Right Front)	11	W10525121	Bracket, Console Mounting
	W10578768	Switch, Infinite (Right Rear)	12	W10871059	Control, Maxwell
	W10437094	Switch, Infinite (Left Rear)	13	3196178	Screw
5		Bracket, Control (Includes Overlay)	14		Bezel
	W10856353	Black		W10918419	Stainless
				W10917223	Black Stainless
			15	W11223046	Antenna
			16	W10432504	Hot Surface Indicator


CHASSIS PARTS



CHASSIS PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10289077	Receiver, Hinge	17	3196548	Fuse, Thermal	35	W10281322	Kit, Bare Wire Adapter Block
2	3196165	Screw	18	3196172	Screw			
3		Panel, Side	19	W10273002	Bracket, Oven Support	36	W10289145	Rack, Oven (Gull-Wing)
	W10162245	Black	20	3186034	Bracket, Service			
4	3400029	Nut	21	W10245259	Block, Terminal	37	9758701	Spacer, Door
5	W10162385	Gasket, Door	22	W10273169	Back, Main	38	W10726740	Shield, Heat
6	W10544951	Element, Broil	23	3196178	Screw	39	W10774446	Bottom, Oven
7	W10774342	Element, Bake	24	W11175594	Assembly, Light	40	W10531060	Rack, Oven
8	W10362924	Screw	25	W10571723	Bulb, Halogen 40 Watts	41	W10910404	Counterweight
9	W10134285	Tube, Vent				42	W11034869	Screw
10	W10035900	Support, Oven Bottom	26	3400016	Screw	43	W10655441	Shield, Power Cord
11	W10341186	Assembly, Front Foot	27	W10181986	Sensor, Oven			FOLLOWING PARTS NOT ILLUSTRATED
12	W10067840	Screw	28	3196169	Screw			
13	W10346147	Pan, Bake	29	W10326122	Cover, Terminal Block		W10194393	Insulation, Wrap
14	W10137382	Clip, Panel	30	W10031780	Screw		W10225524	Insulation, Back
15	W10390007	Assembly, Base Rail (Right)	31	W10273192	Rod, Door Switch		W10225523	Insulation, Bottom
	W10390008	Assembly, Base Rail (Left)	32	W10756304	Assembly, Convection		4820F015-59	Insulation, Strap
16	W10058460	Foot, Leveling	33	W10346154	Cover, Convection			
			34	W10627802	Switch, Door			


DOOR PARTS



DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10813142	Spacer, Glass	9		Glass Assembly, Outer Door	15	W10884775	Nameplate
2	8533988	Screw				16	W10319024	Washer, Door
3		Handle, Door		W10864214	Stainless			
	W10918786	Stainless		W10888239	Black Stainless			
	W10903342	Black Stainless	10		Vent, Trim			
4	W10826568	Liner, Door		W10887939	Black			
5	W10031790	Screw	11	W10327235	Screw			
6	W11088591	Glass, Inner	12	W10813139	Rail, Vertical Support			
7	W10541911	Bracket, Glass Upper Handle	13	W10031780	Screw			
8	W10885519	Hinge, Door (Active)	14	W10813140	Rail, Horizontal Support			

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Panel, Drawer Front	3	W10688022	Drawer, Storage	6		Handle, Door
	W11190211	Stainless	4	W10441804	Slide, Drawer (Left)		W10918786	Stainless
	W11042922	Black Stainless		W10441805	Slide, Drawer (Right)		W10903342	Black Stainless
2	3196169	Screw	5	W10318027	Bracket, Drawer	7	3400882	Screw

OPTIONAL PARTS

REFINISHING MATERIAL

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

INSULATION

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2" x 24" x 120")
	240132	Insulation (2-1/2" x 22" x 120")

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	511873	White Porcelain (2 oz.)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	206922	Primer (White)

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	241430	Aluminum Foil
	3191048	Glass Cleaner
	4396923	Grid, Broiler Pan and Kit, Cooktop Care
	31605	Kit, Cooktop Care
	31463A	Protectant, Cooktop
	W10355049	Wipes, Stainless Steel Cleaning
	W10355016	Cleaner, Stainless Steel
	W10355051	Cleaner, Cooktop
	WA906B	Scraper, Cooktop
	W10432019	Alt Cleaning Kit
	W10275756	Cleaner, Granite
	31617A	Cleaner, Grate & Drip Pan
	4396096RB	Griddle
	4396923	Grid, Broiler Pan and
	W10123240	Rack, Broiler Pan & Roasting